


## Lucas Type Adaptor for 3 Wire Powerlite Alternators



**White:** Warning Light.

**Yellow:** Ignition Wire

**WARNING:**

The ignition wire will draw a constant current from the battery if a master switch is not used. Disconnect from Lucas socket and route to switched ignition source where a master switch is not used.

**Red:** Main Feed.